



### How to switch



### DIP setting:



NOTE! Please disconnect & reconnect interface's power after changing any DIP setting.